

DEVELOPER	Dilution	ISO	Time (mins)	Temperature
510 Pyro	1+100	400	11	20C
510 Pyro	1+100	1600	25	20C
Acufine	1+3	400	10	28C
Acufine	1+3	640	10	28C
D-76	Stock	400	9.5	20C
D-76	1+1	400	14	20C
D-76	Stock	800	12.5	20C
D-76	Stock	1000	14.5	20C
D-76	Stock	1600	20	20C
D-76	1+1	1600	22	20C
HC-110	B	400	5-6	20C
HC-110	E	400	8-9	20C
HC-110	E	800	13	20C
ID-11	Stock	400	9.5	20C
ID-11	1+1	400	16.5	20C
ID-11	Stock	800	13	20C
ID-11	Stock	1000	14.5	20C
ID-11	Stock	1600	20	20C
Ilfosol 3	1+9	400	6.5	20C
Ilfosol 3	1+14	400	11	20C
Ilfosol 3	1+9	800	15	20C
Ilfosol 3	1+14	800	25	20C
Ilfosol 3	1+19	1600	27	18C
Ilfotec DD-X	1+4	400	11.5	20C
Ilfotec DD-X	1+9	400	40	24C
Ilfotec DD-X	1+4	800	13	20C
Ilfotec DD-X	1+4	1600	17	20C
Microphen	Stock	400	8	20C
Microphen	1+1	400	15	20C
Microphen	Stock	800	10	20C
Microphen	1+1	800	19	20C
Perceptol	Stock	400	10	20C

Rodinal	1+25	400	7.5	20C
Rodinal	1+50	400	20	20C
Rodinal	1+25	800	9	20C
Rodinal	1+25	1600	25	20C
TMax Dev	1+4	400	5.5	20C
TMax Dev	1+9	400	10	20C
TMax Dev	1+9	1600	18	20C
XT-3	Stock	400	9	20C
XT-3	1+1	400	12	20C
XT-3	1+2	400	15	20C
XT-3	Stock	800	10.5	20C
XT-3	1+1	800	14.5	20C
XT-3	1+1	1600	13	20C
XT-3	Stock	3200	17.5	20C
XT-3	Stock	6400	21	20C
Xtol	Stock	400	9	20C
Xtol	1+3	400	18	20C
Xtol	Stock	800	10.5	20C
Xtol	1+1	800	14.5	20C
Xtol	Stock	1600	13	20C
Xtol	1+1	1600	18	20C
Xtol	Stock	3200	17.5	20C
Xtol	Stock	6400	21	20C